




Operator's Manual



SNOW THROWER

Model 10530

Polar Blast

IMPORTANT: READ SAFETY RULES AND INSTRUCTIONS CAREFULLY

WARNING: This unit is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator. In the State of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on federal lands. A spark arrester for the muffler is available through your nearest engine authorized service dealer or contact the service department, P.O. Box 361131 Cleveland, Ohio 44136-0019.

TROY-BILT LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

TABLE OF CONTENTS

Content	Page	Content	Page
Important Safe Operation Practices	3	Servicing Your Snow Thrower	15
Assembling Your Snow Thrower	5	Trouble Shooting	19
Know Your Snow Thrower	7	Illustrated Parts	20
Operating Your Snow Thrower	9	Commercial Warranty	31
Making Adjustments	11	Residential Warranty	32
Maintaining Your Snow Thrower	14		

FINDING MODEL NUMBER

This Operator's Manual is an important part of your new snow thrower. It will help you assemble, prepare and maintain the unit for best performance. Please read and understand what it says.



Before you start assembling your new equipment, please locate the model plate on the equipment and copy the information from it in the space provided below. A sample model plate is also given below. You can locate the model plate by standing at the operating position and looking down at the rear of the snow thrower. This information will be necessary to use the manufacturer's web site and/or help from the Customer Support Department or an authorized service dealer.



Copy the model number here: _____

Copy the serial number here: _____

CUSTOMER SUPPORT

Please do NOT return the unit to the retailer from where it was purchased, without first contacting Customer Support.

If you have difficulty assembling this product or have any questions regarding the controls, operation or maintenance of this unit, you can seek help from the experts. Choose from the options below:

	<p>Visit troybilt.com for many useful suggestions. Click on Customer Support button and you will get the four options reproduced here. Click on the appropriate button and help is immediately available.</p> <div style="border: 1px solid black; padding: 5px;"> <p> Find Answers Click here to search our knowledge base. Search by product, keyword, or phrase.</p> <p>My Stuff Login to check the status of your questions, modify your inquiries, or update your personal profile.</p> <p>Service Locator Need local assistance? Click here to find authorized service centers in your area.</p> <p>Manuals Online Need a manual? Download literature for current models.</p> </div> <p style="text-align: right; font-style: italic;"><i>The answer you are looking for could be just a mouse click away!</i></p>
	<p>If you prefer to reach a Customer Support Representative, please call 1-800-520-5520.</p>
	<p>The engine manufacturer is responsible for all engine-related issues with regards to performance, power-rating, specifications, warranty and service. Please refer to the engine manufacturer's Owner's/Operator's Manual, packed separately with your unit, for more information.</p>

SECTION 1: IMPORTANT SAFE OPERATION PRACTICES



This symbol points out important safety instructions, which if not followed, could endanger the personal safety and/or property of yourself and others. Read and follow all instructions in this manual before attempting to operate this machine. Failure to comply with these instructions may result in personal injury. When you see this symbol—**heed its warning**.



WARNING: Engine Exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.



DANGER: This machine was built to be operated according to the rules for safe operation in this manual. As with any type of power equipment, carelessness or error on the part of the operator can result in serious injury. This machine is capable of amputating hands and feet and throwing objects. Failure to observe the following safety instructions could result in serious injury or death.

TRAINING

1. Read, understand, and follow all instructions on the machine and in the manual(s) before attempting to assemble and operate. Keep this manual in a safe place for future and regular reference and for ordering replacement parts.
2. Be familiar with all controls and their proper operation. Know how to stop the machine and disengage them quickly.
3. Never allow children under 14 years old to operate this machine. Children 14 years old and over should read and understand the operation instructions and safety rules in this manual and should be trained and supervised by a parent.
4. Never allow adults to operate this machine without proper instruction.
5. Thrown objects can cause serious personal injury. Plan your snow-throwing pattern to avoid discharge of material toward roads, bystanders and the like.
6. Keep bystanders, helpers, pets and children at least 75 feet from the machine while it is in operation. Stop machine if anyone enters the area.
7. Exercise caution to avoid slipping or falling, especially when operating in reverse.
6. Disengage all controls before starting the engine.
7. Never attempt to make any adjustments while engine is running, except where specifically recommended in the operator's manual.
8. Let engine and machine adjust to outdoor temperature before starting to clear snow.
9. To avoid personal injury or property damage use extreme care in handling gasoline. Gasoline is extremely flammable and the vapors are explosive. Serious personal injury can occur when gasoline is spilled on yourself or your clothes, which can ignite. Wash your skin and change clothes immediately.
 - a. Use only an approved gasoline container.
 - b. Extinguish all cigarettes, cigars, pipes and other sources of ignition.
 - c. Never fuel machine indoors.
 - d. Never remove gas cap or add fuel while the engine is hot or running.
 - e. Allow engine to cool at least two minutes before refueling.
 - f. Never over fill fuel tank. Fill tank to no more than 1/2 inch below bottom of filler neck to provide space for fuel expansion.
 - g. Replace gasoline cap and tighten securely.
 - h. If gasoline is spilled, wipe it off the engine and equipment. Move machine to another area. Wait 5 minutes before starting the engine.
 - i. Never store the machine or fuel container inside where there is an open flame, spark or pilot light (e.g. furnace, water heater, space heater, clothes dryer etc.).
 - j. Allow machine to cool at least 5 minutes before storing.

PREPARATION

1. Thoroughly inspect the area where the equipment is to be used. Remove all doormats, newspapers, sleds, boards, wires and other foreign objects, which could be tripped over or thrown by the auger/impeller.
2. Always wear safety glasses or eye shields during operation and while performing an adjustment or repair to protect your eyes. Thrown objects which ricochet can cause serious injury to the eyes.
3. Do not operate without wearing adequate winter outer garments. Do not wear jewelry, long scarves or other loose clothing, which could become entangled in moving parts. Wear footwear which will improve footing on slippery surfaces.
4. Use a grounded three-wire extension cord and receptacle for all units with electric start engines.
5. Adjust collector housing height to clear gravel or crushed rock surfaces.

OPERATION

1. Do not put hands or feet near rotating parts, in the auger/impeller housing or chute assembly. Contact with the rotating parts can amputate hands and feet.
2. The auger/impeller control is a safety device. Never bypass its operation. Doing so makes the machine unsafe and may cause personal injury.
3. The controls must operate easily in both directions and automatically return to the disengaged position when released.

4. Never operate with a missing or damaged chute assembly. Keep all safety devices in place and working.
5. Never run an engine indoors or in a poorly ventilated area. Engine exhaust contains carbon monoxide, an odorless and deadly gas.
6. Do not operate machine while under the influence of alcohol or drugs.
7. Muffler and engine become hot and can cause a burn. Do not touch.
8. Exercise extreme caution when operating on or crossing gravel surfaces. Stay alert for hidden hazards or traffic.
9. Exercise caution when changing direction and while operating on slopes.
10. Plan your snow-throwing pattern to avoid discharge towards windows, walls, cars etc. Thus, avoiding possible property damage or personal injury caused by a ricochet.
11. Never direct discharge at children, bystanders and pets or allow anyone in front of the machine.
12. Do not overload machine capacity by attempting to clear snow at too fast of a rate.
13. Never operate this machine without good visibility or light. Always be sure of your footing and keep a firm hold on the handles. Walk, never run.
14. Disengage power to the auger/impeller when transporting or not in use.
15. Never operate machine at high transport speeds on slippery surfaces. Look down and behind and use care when in reverse.
16. If the machine should start to vibrate abnormally, stop the engine, disconnect the spark plug wire and ground it against the engine. Inspect thoroughly for damage. Repair any damage before starting and operating.
17. Disengage all controls and stop engine before you leave the operating position (behind the handles). Wait until the auger/impeller comes to a complete stop before unclogging the chute assembly, making any adjustments, or inspections.
18. Never put your hand in the discharge or collector openings. Always use the clean-out tool provided to unclog the discharge opening. Do not unclog chute assembly while engine is running. Shut off engine and remain behind handles until all moving parts have stopped before unclogging.
19. Use only attachments and accessories approved by the manufacturer (e.g. wheel weights, tire chains, cabs etc.).
20. If situations occur which are not covered in this manual, use care and good judgment.


Contact your dealer or telephone **1-800-520-5520** for assistance and the name of your nearest servicing dealer.

MAINTENANCE AND STORAGE

1. Never tamper with safety devices. Check their proper operation regularly. Refer to the maintenance and adjustment sections of this manual.
2. Before cleaning, repairing or inspecting machine disengage all clutch levers and stop engine. Wait until the auger/impeller come to a complete stop. Disconnect the spark plug wire and ground against the engine to prevent unintended starting.
3. Check bolts and screws for proper tightness at frequent intervals to keep the machine in safe working condition. Also, visually inspect machine for any damage.
4. Do not change the engine governor setting or over-speed the engine. The governor controls the maximum safe operating speed of the engine.
5. Snow thrower shave plates and skid shoes are subject to wear and damage. For your safety protection, frequently check all components and replace with original equipment manufacturer's (OEM) parts only. "Use of parts which do not meet the original equipment specifications may lead to improper performance and compromise safety!"
6. Check clutch controls periodically to verify they engage and disengage properly and adjust, if necessary. Refer to the adjustment section in this operator's manual for instructions.
7. Maintain or replace safety and instruction labels, as necessary.
8. Observe proper disposal laws and regulations for gas, oil, etc. to protect the environment.
9. Prior to storing, run machine a few minutes to clear snow from machine and prevent freeze up of auger/impeller.
10. Never store the machine or fuel container inside where there is an open flame, spark or pilot light such as a water heater, furnace, clothes dryer etc.
11. Always refer to the operator's manual for proper instructions on off-season storage.

WARNING — YOUR RESPONSIBILITY:

Restrict the use of this power machine to persons who read, understand and follow the warnings and instructions in this manual and on the machine. The safety labels are shown below for your reference.



SECTION 2: ASSEMBLING YOUR SNOW THROWER

NOTE: All references to right or left side of the snow thrower are determined from behind the unit in the operating position. The “operator’s position” is defined as standing directly behind the snow thrower, facing the handle panel.

Hardware Pack




Figure 1

- The augers are secured to the auger shaft with two shear bolts and flange lock nuts. If you hit a foreign object or ice jam, the snow thrower is designed so that the bolts may shear. Two replacement shear bolts and nuts are provided for your convenience. Store in a safe place until needed. See Figure 1.

IMPORTANT: NEVER replace the auger shear bolts with standard hex bolts. Any damage to the auger gearbox or other components from standard hex bolts will not be covered by your snow thrower’s warranty.

Assembling Handle



WARNING: Disconnect the spark plug wire and ground it against the engine to prevent unintended starting.

IMPORTANT: Make any adjustments, as instructed on Page 11, before operating your snow thrower. Failure to follow these instructions may cause damage to the snow thrower.

- Remove the **lower** plastic wing nut, cupped washer, and carriage bolt from each side of the lower handle. See Figure 2.




Figure 2

NOTE: Before proceeding, look at the lower rear of the snow thrower frame to be sure the spring (found at the end of each cable) is attached to its actuator bracket. See Figure 3.

- Pivot the upper handle assembly forward until it locks over the lower handle. See Figure 2.
- Secure the upper handle and lower handle with the two plastic wing nuts, bell washers and carriage bolts previously removed from the lower hole.
- Firmly tighten all four wing nuts to secure the upper handle to the lower handle.
- Slide the shift rod connector down over the end of the lower shift rod. Tap the connector until it **locks** over the lower shift rod. See Figure 3.

NOTE: If the connector is not properly assembled, the shift rod will pivot and you will not be able to change speeds or change directions.




Figure 3

Attaching Chute Assembly (Hardware Group A)

- Place chute assembly over chute opening, with the opening in the chute assembly facing the front of the unit.
- Place chute flange keepers beneath lip of chute assembly, with the flat side of chute flange keeper facing downward.
- Insert hex screw up through chute flange keeper and chute assembly and secure with hex lock nut. After assembling all three chute flange keepers, tighten all nuts and screws securely with two 7/16" wrenches. Do not overtighten. See Figure 4A.
- With the lock nuts loosened on the lower chute rod bracket (See Figure 4B) adjust the bracket so that the spiral fully engages the teeth on the chute assembly. Tighten the lock nuts on the lower chute rod bracket securely.




Figure 4

Attaching Chute Directional Control

- Remove the hairpin clip from the upper chute rod and slide the upper chute rod through the upper chute rod bracket and into the lower chute rod. See Figure 5.
- Align the two holes on both chute rods and insert the hairpin clip removed earlier, through these holes. See Figure 5.




Figure 5

Routing Chute Tilt Cables

- If not already routed, slip the cables that run from beneath the handle panel to the chute assembly through the cable guide located on top of the engine housing. See Figure 6.




Figure 6

Connecting Alternator Lead

- If not already routed, unwrap the headlight wire which is attached to the headlights, beneath the handle panel. Wind the wire around the lower right handle until excess slack is removed.
- Plug the wire from the headlight into the alternator lead located on the right side of the engine, beneath the fuel tank. See Figure 7.




Figure 7

SECTION 3: KNOW YOUR SNOW THROWER



WARNING: Read, understand, and follow all instructions and warnings on the machine and in this manual before operating.

Throttle Control

The throttle control is located on the engine. It regulates the speed of the engine and also stops the engine. See Figure 8.

Fuel Shut-Off Valve (Optional Equipment)

On models so equipped, the fuel shut-off valve, located under fuel tank, controls fuel-flow from the fuel tank to the engine. See Figure 8.

Safety Ignition Key

The ignition key must be inserted and snapped in place in order for the engine to start. Remove the ignition key to prevent unauthorized use of equipment. *Do NOT "turn" the ignition key in an attempt to start the engine.*

Skid Shoes

The space between the shave plate and the ground can be adjusted by positioning the skid shoes. Refer to **Skid Shoe Adjustment** on page 13.

Shift Lever

The shift lever is located in the center of the handle panel and is used to determine ground speed and direction of travel. It can be moved into any of eight positions. See Figure 8.

IMPORTANT: Always release drive control before changing speeds.

Forward

Your snow thrower has six forward (F) speeds, with position number one (1) being the slowest speed.

Reverse

Your snow thrower has two reverse (R) speeds, with position number one (1) being the slower speed.

Drive Control / Auger Control Lock

The drive control is located on the right handle. Squeeze the drive control to engage the wheel drive. Release to stop. See Figure 8.

The drive control also locks the auger control, so you can operate the chute directional control without interrupting the snow throwing process. If the auger control is engaged simultaneously with the drive control, the operator can release the auger control (on the left handle) and the augers will remain engaged. Release both controls to stop the augers and wheel drive.

IMPORTANT: ALWAYS release the drive control before moving the shift lever. Failure to do so will result in premature wear to the drive system's friction wheel.




Figure 8

Auger Control

The auger control is located on the left handle. Squeeze the auger control to engage the augers. Release to stop the snow throwing action. The drive control must also be released in order to stop the auger.

IMPORTANT: Refer to **Auger Control Test** on page 10 prior to operating your snow thrower. Read and follow all instructions carefully and perform all adjustments to verify your snow thrower is operating safely and properly.

Chute Tilt Control

The distance snow is thrown can be changed by adjusting the angle of the upper chute. Move the chute tilt control forward to decrease the distance, and backwards to increase distance. See Figure 8.

Chute Directional Control

The chute directional control is located on left hand side of the snow thrower. To change the direction which snow is thrown, rotate chute directional control as follows:

- Clockwise to discharge to the left.
- Counterclockwise to discharge to the right.

Headlights

When properly connected, both headlights illuminate whenever the engine is running.

Clean-out Tool



WARNING: Never use your hand to clear a clogged chute. Shut off engine and remain behind handles until all moving parts have stopped before unclogging. Use the clean-out tool or a stick to unclog.

This item, along with the electric cord, is fastened with a cable tie to the rear of the auger housing at the factory. Cut the cable tie and remove the electric cord before operating the snow thrower.

The clean-out tool (see Figure 8) is designed to clear a clogged chute. Refer to page 11 for detailed instructions on how to properly use the clean-out tool.

Wheel Steering Controls

The left and right wheel steering controls are located on the underside of the handles and are used to assist in steering the snow thrower.

- Squeeze the right wheel steering control when turning right; squeeze the left control when turning left.
- Operate the snow thrower in open areas until becoming familiar with these controls.

SECTION 4: OPERATING YOUR SNOW THROWER

Before Starting



WARNING: Read, understand, and follow all instructions and warnings on the machine and in this manual before operating.

Gas And Oil Fill-up

Service the engine with gasoline and oil as instructed in the separate engine manual packed with your snow thrower. **Read instructions carefully.**



WARNING: Use extreme care when handling gasoline. Gasoline is extremely flammable and the vapors are explosive. Never fuel machine indoors or while the engine is hot or running. Extinguish cigarettes, cigars, pipes and other sources of ignition.

- A plastic cap is provided inside the fuel fill opening to protect the tank during manufacturing. Remove and discard. Use the separate threaded fuel tank cap to close after fill-up.

To Start Engine

NOTE: If unit shows any sign of motion (drive or augers) with the controls disengaged, shut engine off immediately. Readjust as instructed on page 10—**Auger Control Test**) and page 11—**Drive Control and Shift Lever**.

- Attach spark plug wire to spark plug. Make certain the metal loop on end of the spark plug wire (inside the boot) is fastened securely over the metal tip on the spark plug.
- Make certain the fuel shut-off valve, if so equipped, is in the OPEN (vertical) position.
- Make certain the auger and drive controls are in the disengaged (up) position.
- Move throttle control up to FAST position. Insert ignition key into slot and snap in place. See Figure 8. **Do not turn key.**

NOTE: Engine will not start unless ignition key is inserted into ignition slot in carburetor cover.

Electric Starter

- Determine that your house wiring is a three-wire grounded system. Ask a licensed electrician if you are not certain.



WARNING: The electric starter is equipped with a grounded three-wire power cord and plug and is designed to operate on 120 volt AC household current. It must be used with a properly grounded three-prong receptacle at all times to avoid the possibility of electric shock. Follow all instructions carefully prior to operating the electric starter.

- If your house wiring system is not a three-wire grounded system, do not use this electric starter under any conditions.
- If your home electrical system is grounded, but a three-hole receptacle is not available, one should be installed by a licensed electrician before using the electric starter.
- If you have a grounded three-prong receptacle, proceed as follows:
- Connect power cord to switch box on engine. Plug the other end of power cord into a three-prong, 120-volt, grounded, AC receptacle.
- Rotate choke knob to FULL choke position (cold engine start). If engine is warm, place choke in OFF position instead of FULL.
- Push primer button two or three times for cold engine start, making sure to cover vent hole in primer button when pushing. DO NOT use primer to restart a warm engine after a short shutdown.
- Push starter button to start engine.
- When engine starts, release starter button, and move choke gradually to OFF. If engine falters, move choke immediately to FULL and then gradually to OFF.
- When disconnecting the power cord, always unplug from the three-prong receptacle first and then from the snow thrower.

Recoil Starter

- Rotate choke knob to FULL choke position (cold engine start). If engine is warm, place choke in OFF position instead of FULL.
- Push primer button three or four times for cold engine start. DO NOT use primer to restart a warm engine after a short shutdown.

NOTE: Always cover vent hole in primer button when pushing. Additional priming may be necessary for first start if temperature is below 15°F.

- Grasp starter handle and pull rope out slowly, until it pulls slightly harder. Let rope rewind slowly.
- Pull starter handle rapidly. Do not allow handle to snap back. Allow it to rewind slowly while keeping a firm hold on the starter handle.
- Repeat the previous steps until engine starts.

- As engine warms up, rotate choke knob slowly to OFF position. If engine falters, return to FULL choke, then slowly move to OFF position.

To Stop Engine

- Run engine for a few minutes before stopping to help dry off any moisture on the engine.
- To help prevent possible freeze-up of starter, proceed as follows:

Electric Starter:

- Connect power cord to switch box on engine, then to 120 volt AC receptacle. With the engine running, push starter button and spin the starter for several seconds. The unusual sound made by spinning the starter will not harm engine or starter. Disconnect the power cord from receptacle first, and then from switch box.

Recoil Starter

- With engine running, pull starter rope with a rapid, continuous full arm stroke three or four times. Pulling the starter rope will produce a loud clattering sound, which is not harmful to the engine or starter.
- Move throttle control to “stop” or “off” position.
- Remove ignition key to prevent unauthorized use of equipment. **Do not turn key.**

NOTE: Keep key in a safe place. Engine will not start without ignition key.

- Wipe all snow and moisture from the carburetor cover in the area of the control levers. Also, move control levers back and forth several times.

To Engage Augers

- To engage augers and start throwing snow, squeeze the auger control against the left handle.
- To disengage power to the augers, release both the auger control and the drive control, if engaged.

The auger control can be locked so you can turn the chute directional control without interrupting the snow throwing process.

Auger Control Test

IMPORTANT: Perform the following test before operating the snow thrower for the first time and at the start of each winter season.

Check the adjustment of the auger control as follows:

- When the auger control is released and in the disengaged “up” position, the cable should have very little slack, but should NOT be tight.



WARNING: Do not over-tighten the cable. Over-tightening may prevent the auger from disengaging and compromise the safety of the snow thrower.

- In a well-ventilated area, start the snow thrower engine as instructed earlier in this section under the heading **Starting Engine**. Make sure the throttle is set in the FAST position.
- While standing in the operator’s position (behind the snow thrower) engage the auger.
- Allow the auger to remain engaged for approximately ten (10) seconds before releasing the auger control. Repeat this several times.
- With the engine running in the FAST position and the auger control in the disengaged “up” position, walk to the front of the machine.
- Confirm that the auger has completely stopped rotating and shows NO signs of motion.

IMPORTANT: If the auger shows ANY signs of rotating, immediately return to the operator’s position and shut off the engine. Wait for all moving parts to stop before readjusting the auger control cable.

- To readjust the control cable, unhook the spring (found on the end of the auger cable) from the auger actuator bracket. See Figure 9.




Figure 9

- Push the cable coupler through the end of the spring to expose the lock nut. See Figure 10.




Figure 10

- Thread the lock nut outward (down the coupler) three full turns to provide more slack in the cable and reattach the spring to the bracket.

- Repeat Auger Control Test to verify proper adjustment has been achieved. Repeat the previous steps to provide more slack in the cable, if necessary.

To Engage Wheel Drive

- With the engine running near top speed, move the shift lever into one of the six FORWARD positions or two REVERSE positions. Select a speed appropriate for the snow conditions.

NOTE: Use slower speeds in heavy conditions and until you are familiar and comfortable with the operation of the snow thrower.

- Squeeze the drive control against the right handle and the snow thrower will move. Release it and the drive motion will stop.

IMPORTANT: NEVER move the shift lever without first releasing the drive control. Doing so will cause premature wear to the drive system's friction wheel.

Wheel Steering Controls

The left and right wheel steering controls are located on the underside of the handles.

- With the traction control engaged, squeeze the right wheel steering control to assist in turning right; squeeze the left control to assist in turning left.

Clean-Out Tool

The clean-out tool is conveniently fastened to the rear of the auger housing with a mounting clip (Refer to Figure 8). If the chute assembly becomes clogged during operation, proceed as follows to safely clean the chute and chute opening:

1. Release both the Auger Control and the Drive/Auger Control Lock.
2. Stop the engine by moving the throttle to the stop position.

3. Remove the clean-out tool from the mounting clip.
4. Use the shovel-shaped end of the clean-out tool to remove any snow and ice in the chute assembly.



WARNING: Never use your hand to clear a clogged chute. Shut off engine and remain behind handles until all moving parts have stopped before unclogging. Use the clean-out tool or a stick to unclog.

5. Refasten the clean-out tool to the mounting clip on the rear of the auger housing, re-start the engine.
6. While standing in the operator's position (behind the snow thrower), engage the auger control for a few seconds to clear any remaining snow or ice from the chute assembly before continuing to clear snow.

Operating Tips



WARNING: The temperature of the muffler and the surrounding areas may exceed 150°F. Avoid these areas.

- Allow the engine to warm up for a few minutes. The engine will not develop full power until it reaches operating temperature.
- For the most efficient snow removal, remove snow immediately after it falls.
- Discharge the snow downwind whenever possible.
- Slightly overlap each previous path.
- Set the skid shoes 1/4" below the shave plate for normal usage. The skid shoes may be adjusted upward (to lower the shave plate) for hard-packed snow. Adjust downward (to raise the shave plate) when using on gravel or crushed rock.

SECTION 5: MAKING ADJUSTMENTS



WARNING: NEVER attempt to clean chute or make any adjustments while engine is running. Always wear safety glasses during operation or while performing any adjustments or repairs.

Drive Control and Shift Lever

To check the adjustment of the drive control and shift lever, proceed as follows:

- Move the shift lever into sixth (6) position.
- With the drive control released, push the snow thrower forward, then pull it back. The machine should move freely.

- Engage the drive control and attempt to move the machine both forward and back, resistance should be felt.
- Move the shift lever into the fast reverse (R2) position and repeat the previous two steps.

If you experienced resistance rolling the unit, either when repositioning the shift lever from 6 to R2 or when attempting to move the machine with the drive control released, adjust the drive control immediately. To adjust, proceed as follows:

- To readjust the drive control cable, unhook the drive spring (found on the end of the drive control

cable) from the drive actuator bracket. See Figure 9.

- Push the cable coupler through the end of the spring to expose the lock nut. See Figure 10.
- Thread the lock nut outward (down the coupler) three full turns to provide more slack in the cable and reattach the spring to the bracket.
- Check the adjustment of the drive control as instructed earlier. Repeat the previous steps to provide more slack in the cable, if necessary.

If you are uncertain that you have reached the correct adjustment, proceed as follows:



WARNING: Drain the gasoline out of your snow thrower's engine, or place a piece of plastic film under the gas cap to avoid spillage before beginning the job.

- Tip the snow thrower forward, allowing it to rest on the auger housing.
- Remove the frame cover underneath the snow thrower by removing six self-tapping screws.
- With the drive control released, make sure there is clearance between the friction wheel and the drive plate in all positions of the shift lever.
- With the drive control lever engaged, make sure the friction wheel solidly contacts the drive plate. See Figure 11.




Figure 11

If adjustment is necessary, adjust drive control as instructed below:

- Thread the lock nut outward (down the coupler) to provide more slack in the cable or thread the lock nut inward (up the coupler) to provide less slack in the cable. Refer to Figure 10.
- Reattach the spring to the bracket.




Figure 12

- Reassemble the frame cover.

NOTE: If you placed plastic film under the gas cap, be certain to remove it before operating the snow thrower.

Shift Rod

If your snow thrower is not achieving its full range of speeds, the shift rod is in need of adjustment. To adjust the shift rod, proceed as follows:

- Remove the hairpin clip and flat washer from the shift handle under the handle panel.
- Place shift lever in sixth (6) position (fastest forward speed).
- Push shift arm assembly down as far as it will go.
- Rotate the ferrule up or down on the shift rod as necessary until the ferrule lines up with the upper hole in the shift lever. See Figure 12.
- Insert ferrule from the left side of the snow thrower into the upper hole.
- Reinstall the hairpin clip and the washer.

NOTE: Make certain to check for correct adjustment of the shift rod as instructed on page 11—**Drive Control and Shift Lever** before operating the snow thrower.

Auger Control

Refer to **Auger Control Test** on page 10 to adjust the auger control. Check for correct adjustment as instructed before operating the snow thrower.

Tire Pressure (Pneumatic Tires)

The tires are overinflated for shipping purposes.

- Check the tire pressure before operating the snow thrower. Refer to the tire side wall for tire manufacturer's recommended psi and deflate (or inflate) the tires as necessary.

NOTE: If the tire pressure is not equal on both sides, the unit may pull to one side or the other.



WARNING: Under any circumstance do not exceed manufacturer's recommended psi. Equal tire pressure should be maintained at all times. Excessive pressure when seating beads may cause tire/rim assembly to burst with force sufficient to cause serious injury. Refer to sidewall of tire for recommended pressure.

Skid Shoe Adjustment

The space between the shave plate and the ground can be adjusted by raising or lowering the skid shoes.

For close snow removal, as when using on a smooth concrete or asphalt driveway, place the skid shoes in the low position. Use the middle or high position when the area to be cleared is uneven. When operating on gravel, always put skid shoes in the high position. See .

Adjust skid shoes as follows:

- Loosen, but do not remove, the three hex nuts which fasten the skid shoe to the auger housing.
- Raise or lower the skid shoe to desired position.
- Retighten the hex nuts loosened earlier.
- Repeat on the other side of the snow thrower.

NOTE: Make certain the bottom surface of skid shoe is flat against the ground to avoid uneven wear.




Figure 13

Chute Assembly

- The distance snow is thrown can be adjusted by adjusting the angle of the upper chute. Refer to **Chute Tilt Control** on page 8.
- The remote chute control cables have been pre-adjusted at the factory. Move the remote chute lever on the control panel back and forward to adjust angle of the upper chute.

SECTION 6: MAINTAINING YOUR SNOW THROWER



WARNING: Before lubricating, repairing, or inspecting, disengage all controls and stop engine. Wait until all moving parts have come to a complete stop. Disconnect the spark plug wire and ground it against the engine to prevent unintended starting. Always wear safety glasses during operation or while performing any adjustments or repairs.

General Recommendations

- Always observe safety rules when performing any maintenance.
- The warranty on this snow thrower does not cover items that have been subjected to operator abuse or negligence.
- Some adjustments will have to be made periodically to maintain your unit properly.
- All adjustments in the service and adjustments sections of this manual should be checked at least once each season.
- Follow the maintenance schedule given below.
- Periodically check all fasteners and hardware to make sure these are tight.

Check V-Belts

Follow the instructions below to check the condition of the drive belts every 50 hours of operation.

- Remove the plastic belt cover on the front of the engine by removing the three self-tapping screws.
- Visually inspect for frayed, cracked, or excessively worn out belts.
- Replace belts as necessary as outlined in **SERVICING YOUR SNOW THROWER**.

Lubrication

Auger Shaft

- At least once a season, remove the shear bolts from the auger shaft and spray lubricant inside the shaft. See Figure 14.
- Grease fittings can be found at either end of the auger shaft. Lubricate with a grease gun once a season. See Figure 14.

Gear Case

The auger gear case is equipped with a grease fitting. Lubricate with Shell Alvania lead-free grease once a season (order part number 737-0168). See Figure 14.

IMPORTANT: To relieve pressure, remove the vent plug before lubricating the gear case. See Figure 14. Failure

to do so could result in damage to the gear case seals.




Figure 14

Chute Assembly

The base of the chute assembly and the spiral on the chute directional control should be lubricated at least every 25 hours of use. Apply the lubricant under the base of the chute assembly and where the spiral contacts the chute assembly. See Figure 15.




Figure 15

Drive and Shifting Mechanism

At least once a season or after every 25 hours of operation, remove rear cover. Lubricate any chains, sprockets, gears, bearings, shafts, and the shifting mechanism at least once a season. Use engine oil or a spray lubricant. Avoid getting oil on friction wheel and aluminum drive plate. Refer to Figure 11.

Gear Shaft

Lubricate the gear shaft with 6-in-1 grease (part number 737-0170) at least once a season, or after every 25 hours of operation. Refer to Figure 11.




Figure 16

IMPORTANT: Be careful not to allow grease to get on the drive plate or friction wheel.

Drive Control / Auger Control Lock

The cams on the ends of the control rods which interlock the drive and auger controls must be lubricated at least once a season or every 25 hours of operation using a multi-purpose automotive grease. The cams can be accessed beneath the handle panel. See Figure 16.

Engine

Refer to the separate engine manual packed with your unit for all engine lubrication instructions.

Bonded Friction Wheel

Follow the instructions below to check the condition of the bonded friction wheel every 25 hours of operation.

- Remove the six self-tapping screws from the frame cover underneath the snow thrower.
- Visually inspect the bonded friction wheel for excessive wear, cracks, or loose fit on the friction wheel drive hub.
- Also engage the drive control and check if the friction wheel is making contact with the friction plate. Refer to Figure 11.
- If it does not make contact, adjust the drive cable and recheck the friction wheel.
- Replace bonded friction wheel if necessary. Refer to instructions in Service Section on Page 17.

SECTION 7: SERVICING YOUR SNOW THROWER



WARNING: Before servicing, repairing, or inspecting, disengage all controls and stop engine. Wait until all moving parts have come to a complete stop. Disconnect spark plug wire and ground it against the engine to prevent unintended starting. Always wear safety glasses during operation or while performing any adjustments or repairs.

Augers

The augers are secured to the spiral shaft with two shear bolts and flange lock nuts. If you hit a foreign object or ice jam, the snow thrower is designed so that the bolts may shear. See Figure 17.

If the augers do not turn, check if the bolts have sheared. Two replacement shear bolts and flange lock nuts have been provided with the snow thrower. Refer to **Hardware Pack** on page 5.

IMPORTANT: NEVER replace the auger shear bolts with standard hex bolts. Any damage to the auger gearbox or other components, as a result of doing so, will NOT be covered by your snow thrower's warranty.

Shave Plate and Skid Shoes

The shave plate and skid shoes on the bottom of the snow thrower are subject to wear. They should be checked periodically and replaced when necessary.

NOTE: The skid shoes on this machine have two wear edges. When one side wears out, they can be rotated 180° to use the other edge.

- Remove the six carriage bolts (three per side), and flange lock nuts which secure the skid shoes to the snow thrower on either side. See .
- Reassemble new skid shoes with the hardware removed earlier. Make certain the skid shoes are adjusted to be level. Refer to .
- To remove the shave plate, remove the carriage bolts, and flange lock nuts which secure the shave plate to the snow thrower housing. See Figure 17.




Figure 17

- Reassemble the new shave plate, making sure heads of carriage bolts are to the inside of the housing. Tighten securely.

Replacing Belts

To remove and replace either the auger belt or the drive belt, follow the steps below and then proceed to the specific steps listed under respective sub-headings.

- Disconnect the chute directional control at the chute assembly base by removing the hairpin clip and the flat washer. See Figure 18.
- Remove the plastic belt cover, located near the engine, by removing the three self-tapping screws and flat washers that secure it. See Figure 18.




Figure 18

- Remove the large shoulder bolt and washer on the left hand side of the engine pulley. See Figure 19.




Figure 19

Auger Belt

- Remove the cotter pin and washer from the ferrule in order to disconnect the auger idler rod from the brake bracket assembly. See Figure 20.




Figure 20

- Slip the auger control belt (the front belt) off the engine pulley.
- Pull the brake bracket assembly towards the cable guide roller and unhook the auger cable "Z" fitting.
- Remove the upper bolts and lock washers which secure the auger housing assembly to the frame assembly using a 9/16" wrench. See Figure 18.
- Separate the auger housing from the frame assembly by tilting the housing forward and pulling up the handles.
- Using a 1/2" wrench, remove the hex bolt and bell washer from the center of the pulley on the auger housing. Lift the brake bracket assembly out of the pulley groove and remove the pulley. Be careful not to lose the key. See Figure 21.




Figure 21

- Remove and replace auger belt inside belt keepers.
- Reassemble pulley to auger housing with hex bolt and bell washer (cupped side toward the pulley). Make sure key is in place on shaft and brake puck is seated in the pulley groove.
- Reassemble the belt cover and chute directional control.

Proper Adjustment: With the auger control in the disengaged position the top surface of the new belt should be even with the outside diameter of the pulley.

- To adjust, disconnect ferrule from brake bracket assembly and thread ferrule in (towards idler) to increase tension on belt, and out to decrease tension.

NOTE: The brake puck must always be firmly seated in the pulley groove when the auger control is in the disengaged position.

Drive Belt

- Unhook the extension spring from the belt cover plate. See Figure 22.
- Remove drive belt from the engine pulley and bottom drive pulley. Refer to Figure 22.




Figure 22

- Replace belt and reassemble in reverse order.
- Reassemble the two halves of the unit hooking the lower portion of the auger housing over the stationary shoulder bolts in the frame assembly.
- Secure the two halves with the two bolts and lock washers removed earlier. Refer to Figure 18.
- Attach the "Z" fitting of the cable into the brake bracket assembly. Refer to Figure 20.
- Slip the auger control belt over engine pulley.
- Insert ferrule on auger idler rod into bracket assembly and secure with flat washer and cotter pin. Reassemble the large shoulder bolt and lock washer as shown in Figure 19.
- Reassemble belt cover and chute directional control.

Changing Bonded Friction Wheel

The bonded friction wheel is subject to wear and should be checked after the first 25 hours of operation, and periodically thereafter. Replace the bonded friction wheel if any signs of wear or cracking are found.

- Drain the gasoline from the snow thrower, or place a piece of plastic under the gas cap.
- Tip the snow thrower up and forward, so that it rests on the housing.
- Remove six screws from the frame cover underneath the snow thrower.
- Remove the left wheel from the axle.
- Using a 7/8" wrench, hold the hex shaft and remove the hex bolt, bell washer and bearing from left side of the frame.
- Holding the friction wheel assembly, slide the hex shaft out of the left side of the unit. The spacer on the right side of the hex shaft will fall and the sprocket should remain hanging loose in the chain. See Figure 23A.
- Lift the friction wheel assembly out between the axle shaft and the drive shaft assemblies.
- Remove four screws securing the friction wheel assembly together. See Figure 23B.
- Discard old bonded friction wheel.
- Reassemble the new bonded friction wheel to the friction wheel assembly, tightening the four screws in rotation and with equal force.
- Insert the pin from the shift arm assembly into the friction wheel assembly and hold assembly in position. See Figure 23A.
- Slide the hex shaft through the left side of the housing and through the friction wheel assembly.
- Insert the hex shaft through the sprocket and the spacer. Make certain that the chain engages both the large and the small sprocket. See Figure 24.




Figure 23




Figure 24

NOTE: If the sprocket fell from the snow thrower while removing the hex shaft, place the sprocket on the hex shaft. Position the hex hub of the sprocket toward the friction wheel when sliding the sprocket on to the hex shaft. See Figure 24.

- Secure with the bell washer and hex bolt removed earlier.
- Secure the frame cover with six self-tapping screws. Put the snow thrower down to its normal operating position.

NOTE: If you placed plastic film under the gas cap, be certain to remove it.

Off-Season Storage



WARNING: Never store engine with fuel in tank indoors or in poorly ventilated areas, where fuel fumes may reach an open flame, spark or pilot light as on a furnace, water heater, clothes dryer or other gas appliance.

- If unit is to be stored over 30 days, prepare engine for storage as instructed in the engine manual.
- Remove all debris from the exterior of equipment.
- Follow lubrication recommendations on page 14.
- Always store the snow thrower in a clean, dry area.


NOTE: When storing any type of power equipment in an unventilated or metal storage shed, care should be taken to rust proof the equipment. Using a light oil or silicone, coat the equipment, especially any chains, springs, bearings, and cables.

SECTION 8: TROUBLESHOOTING


Problem	Cause	Remedy
Engine fails to start.	<ol style="list-style-type: none"> 1. Fuel tank empty, or stale fuel. 2. Blocked fuel line. 3. Choke not in ON position 4. Faulty spark plug. 5. Safety key not in ignition switch on engine. 6. Spark plug wire disconnected. 7. Primer button not being used properly. 8. Fuel shut-off valve closed. (If Equipped) 	<ol style="list-style-type: none"> 1. Fill tank with fresh gasoline. 2. Clean the fuel line. 3. Move switch to ON position 4. Clean, adjust gap or replace. 5. Insert the key fully into the switch. 6. Connect spark plug wire. 7. Refer to the engine manual. 8. Open fuel shut-off valve. (If Equipped)
Engine runs erratic.	<ol style="list-style-type: none"> 1. Unit running on CHOKE. 2. Blocked fuel line or stale fuel. 3. Water or dirt in fuel system. 4. Carburetor out of adjustment. 	<ol style="list-style-type: none"> 1. Move choke lever to OFF position. 2. Clean fuel line and fill tank with clean, fresh gasoline. 3. Drain fuel tank and carburetor. Refill with fresh fuel. 4. Refer to the engine manual.
Loss of power.	<ol style="list-style-type: none"> 1. Spark plug wire loose. 2. Gas cap vent hole plugged. 3. Exhaust port plugged. 	<ol style="list-style-type: none"> 1. Connect and tighten spark plug wire. 2. Remove ice and snow from gas cap. Be certain vent hole is clear. 3. Refer to the engine manual.
Engine overheats.	<ol style="list-style-type: none"> 1. Carburetor not adjusted properly. 	<ol style="list-style-type: none"> 1. Refer to the engine manual or have the carburetor adjusted by an authorized engine service dealer.
Excessive vibration.	<ol style="list-style-type: none"> 1. Loose parts or damaged auger. 	<ol style="list-style-type: none"> 1. Stop engine immediately and disconnect spark plug wire. Tighten all bolts and nuts. If vibration continues, have unit serviced by an authorized service dealer.
Unit fails to propel itself.	<ol style="list-style-type: none"> 1. Drive control cable in need of adjustment. 2. Drive belt loose or damaged. 	<ol style="list-style-type: none"> 1. Adjust drive control cable. Refer to Adjustments. 2. Replace drive belt.
Unit fails to discharge snow.	<ol style="list-style-type: none"> 1. Chute assembly clogged. 2. Foreign object lodged in auger. 3. Auger control cable in need of adjustment. 4. Auger belt loose or damaged. 5. Shear bolt(s) sheared. 	<ol style="list-style-type: none"> 1. Stop engine immediately and disconnect spark plug wire. Clean chute and inside of auger housing with clean-out tool or stick. 2. Stop engine immediately and disconnect spark plug wire. Remove object from auger with clean-out tool or stick. 3. Refer to Auger Control Test on Page 10. 4. Refer to Adjustments. 5. Replace shear bolt(s).

NOTE: For repairs beyond the minor adjustments listed above, contact an authorized Troy-Bilt service dealer.

SECTION 9: PARTS LIST FOR MODEL 10530




REAR VIEW



Model 10530

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	05244A	Bearing Housing	34.	741-0494	Flange Bushing
2.	618-0281A	Auger Brake Bracket Assembly	35.	747-0980	Auger Idler Rod
3.	684-0090A	16" Impeller Assembly	36.	754-0222A	V-Belt
4.	710-0371	Hex Lock Bolt 5/16-18 x .875"	37.	756-0178	Flat Idler
5.	710-0451	Carriage Bolt 5/16-18 x .750"	38.	756-0243	Pulley
6.	710-0459A	Hex Screw, Special 3/8-24 x 1.5"	39.	784-0385A	Auger Idler Bracket
7.	710-0528	Hex Screw 5/16-18 x 1.25"	40.	784-5076	Support Bracket
8.	710-0726	Self-Tapp. Screw 5/16-12 x .750"	41.	784-5123	Chute Directional Control Bracket
9.	710-0891	Shear Bolt 5/16-18 x 1.75"	42.	784-5710	Support Plate
10.	711-0640	Stud	43.	784-5711	Chute Bracket
11.	711-0677	Ferrule	44.	618-0436	Gear Assembly
12.	712-0116	Jam Nut 3/8-24	45.	705-5206A	Spiral Assembly 30" RH
13.	712-04063	Flange Lock Nut, 5/16-18	46.	705-5207A	Spiral Assembly 30" LH
15.	714-0104	Hairpin Clip	47.	684-04006	30' Auger Housing Assembly
16.	714-0126	Key	48.	784-5697	Skid Shoe
17.	714-0135	Key	49.	737-3000	Lube Fitting
18.	715-0118	Spiral Pin	50.	710-3008	Screw, 5/16-18 x .75"
19.	731-1696A	Chute Adapter	52.	784-0315	Bearing Housing
20.	732-0858	Extension Spring	53.	784-5715A	30" Shave Plate
23.	736-0169	Lock Washer	54.	710-0389	Carriage Screw
24.	736-0174	Wave Washer	55.	710-3168	Carriage Bolt
25.	736-0242	Belleville Washer	56.	712-04065	Flange Lock Nut, 3/8-16
26.	736-0250	Flat Washer	57.	710-1260A	Screw, 5/16-18 x .75
27.	736-0271	Spring Washer	58.	712-0717	Insert Nut, 3/8-16
28.	736-3008	Flat Washer	59.	731-2643	Clean-out Tool
30.	738-0281	Shoulder Screw	60.	731-2635	Clean-out Tool Mount
31.	741-04024	Self-Aligning Bearing	61.	738-0733B	Spiral Axle
32.	741-0192	Flange Bearing w/ Flats			
33.	741-0475	Plastic Bushing			


Model 10530



Model 10530

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	741-0225	Hex Flange Bearing	49.	710-0726	Self-tapping Screw, 5/16-12 x.750
2.	750-1302A	Spacer,.6725 x 1.125 x 2.485	50.	736-0300	Flat Washer
3.	618-0279	Dogg Assembly LH	51.	736-0329	Lock Washer
4.	618-0280	Dogg Assembly RH	52.	736-0623	Flat Washer
5.	618-0282D	Drive Shaft Assembly	53.	712-0717	Nut Insert, 3/8-16
6.	618-04178	Friction Wheel Assembly	54.	784-0404	Bearing Retainer Bracket
7.	684-0162	Support Bracket Assembly	55.	784-0407	Axle Bearing Support Bracket
8.	684-0161	Shift Arm Assembly	56.	738-0143	Shoulder Screw
9.	684-04103	Shift Rod Assembly	57.	738-0279	Drive Plate Spindle
10.	684-0118	Auger Actuator Bracket Assy.	58.	738-0924	Shoulder Screw 1/4-28 x .375"
11.	684-0119	Drive Actuator Bracket Assy.	59.	741-0163A	Bearing Housing Assembly
12.	790-00016	Frame Assembly	60.	714-0151A	Click Pin
13.	684-0122	Sprocket Assembly	61.	741-0563	Ball Bearing
14.	710-0195	Hex Screw, 1/4-28 x.625"	62.	741-0747	Ball Bearing
15.	710-0538	Hex Screw, 5/16-18 x.625"	63.	746-0949A	Steer Cable
16.	710-0599	Self-tapping Screw, 1/4-20 x.5	64.	746-0951	Auger Idler Cable
17.	710-0788	Self-tapping Screw, 1/4-20 x 1"	65.	747-0973	Drive Clutch Rod
18.	710-0896	Self-tapping Screw, 1/4-14 x.625"	66.	750-0903	Split Spacer
19.	710-3001	Hex Screw 3/8-16 x .880"	67.	750-0997	Spacer
20.	710-3008	Hex Screw 5/16-18 x .75"	68.	741-0748	Flange Bearing
21.	710-3103	Hex Screw 5/16-18 x 2"	69.	737-3000	Lube Fitting, 3/16
22.	710-3180	Hex Screw 5/16-18 x 1.75"	70.	756-0344	Drive Pulley
23.	711-04279	Hex Drive Shaft	71.	756-0625	Roller Cable
24.	711-1193	Actuator Shaft	72.	784-0406	Frame Support Bracket
25.	711-1194	Actuator Drive Shaft	73.	784-0379	Upper Frame Cover
26.	712-0116	Lock Nut	74.	784-0380	Lower Frame Cover
27.	712-0138	Hex Nut 1/4-28	75.	784-0384	Auger Cable Bracket
28.	712-0221	Jam Lock Nut	76.	784-0403	Shift Bracket
29.	712-04063	Flange Lock Nut, 5/16-18	77.	710-1879	Hex Screw 3/8-16 x.880
30.	712-0798	Hex Nut 3/8-16	78.	718-04034	Bonded Friction Wheel
31.	712-3010	Hex Nut 5/16-18	79.	790-00011	Friction Wheel Plate
32.	713-0284	Chain	80.	718-04070	Friction Wheel Hub
33.	713-0286	Chain	81.	618-04169	Friction Wheel Bearing Assembly
34.	713-04015	Sprocket, 10T	82.	738-1166A	Wheel Axle
35.	714-0101	Hairpin Clip	83.	634-0225	Wheel Assembly, LH
36.	714-0104	Hairpin Clip	—	734-2031	X-Trac Tire Only
37.	714-0115	Cotter Pin	—	734-1124	Rim Only
38.	714-0388	Key	—	734-0255	Air Valve Only
39.	716-0136	Retainer Ring	—	741-0246A	Bearing
40.	717-0302	Drive Plate	84.	634-0226	Wheel Assembly, RH
41.	732-0121	Extension Spring	—	734-2031	X-Trac Tire Only
42.	732-0209	Extension Spring	—	734-1124	Rim Only
43.	736-0119	Lock Washer 5/16	—	734-0255	Air Valve Only
44.	736-0158	Lock Washer 5/8	—	741-0246A	Bearing
45.	736-0160	Flat Washer	85.	05244A	Bearing Housing
46.	736-0163	Flat Washer	86.	741-04025	Self Aligning Bearing
47.	736-0217	Lock Washer	87.	712-04065	Flange Lock Nut, 3/8-16
48.	736-0242	Bell Washer			


Model 10530



Model 10530


Ref. No.	Part No.	Part Description
1.	646-0012	Auger/Drive Cable Assembly
2.	684-0053B	Lower Chute Directional Control
3.	705-5266	Split Chute Directional Control Brkt.
4.	710-1879	Hex Screw, 3/8-16 x .88"
5.	710-1878	Hex Screw, 3/8-16 x 1.75"
6.	710-0458	Carriage Bolt 5/16-18 x 1.75"
7.	710-0572	Carriage Bolt 5/16-18 x 2.5"
8.	747-1136	Lamp Retainer
9.	710-0597	Hex Screw 1/4-20 x 1.00"
10.	711-0677	Ferrule
11.	712-04064	Flange Lock Nut, 1/4-20
12.	629-04010	Lamp Wire Harness
13.	712-3010	Hex Nut
14.	714-0101	Hairpin Clip
15.	714-0104	Hairpin Clip
16.	720-0201A	Chute Directional Control Knob
17.	720-0284	Knob
18.	726-0100	Push Cap
19.	736-0105	Bell Washer
20.	736-0185	Flat Washer
21.	736-0242	Belleville Washer
23.	736-0275	Flat Washer
24.	741-0475	Plastic Bushing
25.	747-0624	Chute Directional Control
26.	747-0983A	Lower Shift Rod
27.	747-0997	Upper Shift Rod
28.	749-0989A	Upper Handle LH
29.	749-0990A	Upper Handle RH
30.	749-0991	Lower Handle
31.	750-0963	Shift Rod Connector
32.	710-1625	Oval C-Sunk Screw
34.	725-0157	Cable Tie
35.	746-0950A	Trigger Control
36.	725-1658	Halogen Lamp
37.	705-5218	Handle Engagement RH
38.	705-5219	Handle Engagement LH
39.	710-1003	Special B Screw
40.	712-0271	Hex Sems Nut
42.	720-0232	Shift Knob
43.	731-04069	Handle Panel
44.	725-1672	Lens Assembly

Model 10530



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	07386	Washer	18.	748-0234	Shoulder Spacer
2.	684-0123A	Belt Cover Bracket Assembly	19.	754-0131	V-Belt
3.	710-0191	Hex Screw 3/8-24 x 1.25"	20.	756-0240	Flat Idler
4.	710-0237	Hex Screw 5/16-24 x .625"	21.	756-0241B	Double Pulley
5.	710-1008	Self-tapping Sems Screw	22.	784-5726	Idler Bracket
6.	710-0607	TT Screw 5/16-18 x 0.5"	23.	750-1148A	Spacer
7.	710-0672	Hex Lock Screw 5/16-24 x 1.25"	24.	748-0418	Spacer, .33 x 1.0 x .36
8.	712-0116	Jam Nut	25.	717-0882A	Spacer
9.	714-0118	Key	26.	629-0071	Extension Cord: 110V, 3-prong
10.	731-2531	Belt Cover	27.	684-04011	Spark Plug Cap
11.	732-0303	Extension Spring	28.	684-04014A	Engine Shroud (Incl. Ref. 27)
13.	736-0217	Lock Washer	29.	710-04082	Screw, #10-16 x .75
14.	736-0242	Beleville Washer	30.	712-3004A	Flange Lock Nut, 5/16-18
15.	736-0264	Flat Washer			
17.	738-0982	Shoulder Screw			


Model 10530



Ref. No.	Part No.	Description
1.	618-0246	Housing Assembly, RH
2.	618-0435	Housing Assembly, LH
3.	710-1260A	Screw, 5/16-18 x 0.75
4.	738-0492	Spiral Axle
5.	711-1133	Auger Drive Shaft
6.	714-0126	Hi Pro Key, 3/16 x 3/4 (Not Shown)
7.	714-0135	#91 Woodruff Key 1/4 x 3/4
8.	716-0111	Snap Ring,.875 Dia.
9.	717-0299	Double Thread Worm Gear LH
10.	717-1425	Worm Gear, LH
11.	721-0145	Oil Seal,.875 ID
12.	721-0325	Plug, 1/4 x.437
13.	736-0266	Flat Washer, 1.52 x 2.0
14.	736-0291	Flat Washer,.88 x 1.38
15.	737-3000	Lube Fitting, 3/16 Drive
16.	738-0275	Worm Gear Shaft
17.	741-0184	Thrust Bearing,.877 ID
18.	741-0217	Sleeve Bearing,.877 x.125 x 1.11
19.	618-0436	Auger Gearbox Assembly Complete

NOTE: When rebuilding a gearbox assembly, include 3 oz. of Shell Alvania EP Lead-Free Grease (Part No. 737-0168).

Model 10530



Ref. No.	Part No.	Description
1.	710-0276	Carriage Screw
2.	710-0458	Carriage Bolt 5/16-18 x 1.75"
3.	710-0805	Hex Bolt 5/16-18 x 1.5"
4.	710-0895	Hex Screw 1/4-15 x .750"
5.	710-0597	Hex Screw 1/4-20 x 1.00"
6.	712-04063	Flange Lock Nut, 5/16-18
7.	712-04064	Flange Lock Nut, 1/4-20
8.	731-0846C	Upper Chute
9.	731-0851A	Chute Flange Keeper
10.	731-1313C	Chute Tilt Cable Guide
11.	731-0903D	Lower Chute
12.	784-5680	Handle Suppt. Bracket 5/8 RH
14.	736-0231	Flat Washer
15.	736-0506A	Special Washer
16.	746-0902	Chute Control Cable
17.	746-0903	Chute Cable w/Clip
18.	784-5594	Cable Bracket
19.	784-5604	Chute Tilt Handle
20.	684-0102	Handle Panel Assembly w/ Tilt
21.	710-0459A	Hex Bolt 3/8-24 x 1.5"
22.	710-0599	TT Screw 1/4-20 x 0.5"
23.	711-0653	Clevis Pin
24.	712-0116	Jam Nut
25.	784-5682	Handle Suppt. Bracket 3/8 RH
26.	714-0104	Cotter Pin
27.	732-0145	Spring
28.	732-0193	Spring
29.	732-0746	Torsion Spring
30.	735-0199A	Rubber Bumper
31.	736-0105	Bell Washer
32.	784-5681	Handle Suppt. Bracket 3/8 LH
33.	736-0509	Special Washer
34.	747-0877	Cam Rod
35.	748-0362	Cam Handle Lock
36.	748-0363	Handle Lock Pawl
37.	784-5619A	Shift Handle
38.	784-5679	Handle Suppt. Bracket 5/8 LH
39.	714-0507	Cotter Pin

NOTES

NOTES

MANUFACTURER'S LIMITED COMMERCIAL WARRANTY FOR:



The limited warranty set forth below is given by Troy-Bilt LLC with respect to new merchandise used for commercial purposes and purchased and used in the United States and/or its territories and possessions, and by MTD Products Limited with respect to new merchandise purchased and used in Canada and/or its territories and possessions (either entity respectively, "Troy-Bilt").

"Troy-Bilt" warrants this product (excluding its normal wear parts as described below) against defects in material and workmanship for a period of ninety (90) days commencing on the date of original purchase and will, at its option, repair or replace, free of charge, any part found to be defective in materials or workmanship. This limited warranty shall only apply if this product has been operated and maintained in accordance with the Operator's Manual furnished with the product, and has not been subject to misuse, abuse, neglect, accident, improper maintenance, alteration, vandalism, theft, fire, water, or damage because of other peril or natural disaster. Damage resulting from the installation or use of any part, accessory or attachment not approved by Troy-Bilt for use with the product(s) covered by this manual will void your warranty as to any resulting damage.

Normal wear parts are warranted to be free from defects in material and workmanship for a period of thirty (30) days from the date of purchase. Normal wear parts include, but are not limited to items such as: batteries, belts, blades, blade adapters, grass bags, rider deck wheels, seats, snow thrower skid shoes, friction wheels, shave plates, auger spiral rubber and tires.

HOW TO OBTAIN SERVICE: Warranty service is available, WITH PROOF OF PURCHASE, through your local authorized service dealer. To locate the dealer in your area:

In the U.S.A.

Check your Yellow Pages, or contact Troy-Bilt LLC at P.O. Box 361131, Cleveland, Ohio 44136-0019, or call 1-866-840-6483 or 1-330-558-7220, or log on to our Web site at www.troybilt.com.

In Canada

Contact MTD Products Limited, Kitchener, ON N2G 4J1, or call 1-800-668-1238 or log on to our Web site at www.mtdcanada.com.

This limited warranty does not provide coverage in the following cases:

- a. The engine or component parts thereof. These items may carry a separate manufacturer's warranty. Refer to applicable manufacturer's warranty for terms and conditions.
- b. Log splitter pumps, valves, and cylinders have a separate one- year warranty.

- c. Routine maintenance items such as lubricants, filters, blade sharpening, tune-ups, brake adjustments, clutch adjustments, deck adjustments, and normal deterioration of the exterior finish due to use or exposure.
- d. Service completed by someone other than an authorized service dealer.
- e. Troy-Bilt does not extend any warranty for products sold or exported outside of the United States and/or Canada, and their respective possessions and territories, except those sold through Troy-Bilt's authorized channels of export distribution.
- f. Replacement parts that are not genuine Troy-Bilt parts.
- g. Transportation charges and service calls.

No implied warranty, including any implied warranty of merchantability of fitness for a particular purpose, applies after the applicable period of express written warranty above as to the parts as identified. No other express warranty, whether written or oral, except as mentioned above, given by any person or entity, including a dealer or retailer, with respect to any product, shall bind Troy-Bilt. During the period of the warranty, the exclusive remedy is repair or replacement of the product as set forth above.

The provisions as set forth in this warranty provide the sole and exclusive remedy arising from the sale. Troy-Bilt shall not be liable for incidental or consequential loss or damage including, without limitation, expenses incurred for substitute or replacement lawn care services or for rental expenses to temporarily replace a warranted product.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you.

In no event shall recovery of any kind be greater than the amount of the purchase price of the product sold. **Alteration of safety features of the product shall void this warranty.** You assume the risk and liability for loss, damage, or injury to you and your property and/or to others and their property arising out of the misuse or inability to use the product.

This limited warranty shall not extend to anyone other than the original purchaser or to the person for whom it was purchased as a gift.

HOW LOCAL LAWS RELATE TO THIS WARRANTY: This limited warranty gives you specific legal rights, and you may also have other rights that vary in different jurisdictions.

IMPORTANT: Owner must present Original Proof of Purchase to obtain warranty coverage.

MANUFACTURER'S LIMITED WARRANTY FOR:



The limited warranty set forth below is given by Troy-Bilt LLC with respect to new merchandise purchased and used in the United States and/or its territories and possessions, and by MTD Products Limited with respect to new merchandise purchased and used in Canada and/or its territories and possessions (either entity respectively, "Troy-Bilt").

"Troy-Bilt" warrants this product (excluding its normal wear parts as described below) against defects in material and workmanship for a period of two (2) years commencing on the date of original purchase and will, at its option, repair or replace, free of charge, any part found to be defective in materials or workmanship. This limited warranty shall only apply if this product has been operated and maintained in accordance with the Operator's Manual furnished with the product, and has not been subject to misuse, abuse, commercial use, neglect, accident, improper maintenance, alteration, vandalism, theft, fire, water, or damage because of other peril or natural disaster. Damage resulting from the installation or use of any part, accessory or attachment not approved by Troy-Bilt for use with the product(s) covered by this manual will void your warranty as to any resulting damage.

Normal wear parts are warranted to be free from defects in material and workmanship for a period of thirty (30) days from the date of purchase. Normal wear parts include, but are not limited to items such as: batteries, belts, blades, blade adapters, grass bags, rider deck wheels, seats, snow thrower skid shoes, friction wheels, shave plates, auger spiral rubber and tires.

HOW TO OBTAIN SERVICE: Warranty service is available, WITH PROOF OF PURCHASE, through your local authorized service dealer. To locate the dealer in your area:

In the U.S.A.

Check your Yellow Pages, or contact Troy-Bilt LLC at P.O. Box 361131, Cleveland, Ohio 44136-0019, or call 1-866-840-6483 or 1-330-558-7220, or log on to our Web site at www.troybilt.com.

In Canada

Contact MTD Products Limited, Kitchener, ON N2G 4J1, or call 1-800-668-1238 or log on to our Web site at www.mtdcanada.com.

This limited warranty does not provide coverage in the following cases:

- The engine or component parts thereof. These items may carry a separate manufacturer's warranty. Refer to applicable manufacturer's warranty for terms and conditions.
- Log splitter pumps, valves, and cylinders have a separate one- year warranty.
- Routine maintenance items such as lubricants, filters, blade sharpening, tune-ups, brake adjustments, clutch adjustments, deck adjustments, and normal

deterioration of the exterior finish due to use or exposure.

- Service completed by someone other than an authorized service dealer.
- Troy-Bilt does not extend any warranty for products sold or exported outside of the United States and/or Canada, and their respective possessions and territories, except those sold through Troy-Bilt's authorized channels of export distribution.
- Replacement parts that are not genuine Troy-Bilt parts.
- Transportation charges and service calls.
- If Products are used commercially. (*Troy-Bilt may separately offer Limited Commercial Warranties on certain select products. Ask your dealer or retailer for details or contact Troy-Bilt Service for more information.*)

No implied warranty, including any implied warranty of merchantability of fitness for a particular purpose, applies after the applicable period of express written warranty above as to the parts as identified. No other express warranty, whether written or oral, except as mentioned above, given by any person or entity, including a dealer or retailer, with respect to any product, shall bind Troy-Bilt. During the period of the warranty, the exclusive remedy is repair or replacement of the product as set forth above.

The provisions as set forth in this warranty provide the sole and exclusive remedy arising from the sale. Troy-Bilt shall not be liable for incidental or consequential loss or damage including, without limitation, expenses incurred for substitute or replacement lawn care services or for rental expenses to temporarily replace a warranted product.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you.

In no event shall recovery of any kind be greater than the amount of the purchase price of the product sold. **Alteration of safety features of the product shall void this warranty.** You assume the risk and liability for loss, damage, or injury to you and your property and/or to others and their property arising out of the misuse or inability to use the product.

This limited warranty shall not extend to anyone other than the original purchaser or to the person for whom it was purchased as a gift.

HOW LOCAL LAWS RELATE TO THIS WARRANTY: This limited warranty gives you specific legal rights, and you may also have other rights that vary in different jurisdictions.

IMPORTANT: Owner must present Original Proof of Purchase to obtain warranty coverage.

Troy-Bilt LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019; Phone: 1-866-840-6483, 1-330-558-7220
MTD Canada Limited - KITCHENER, ON N2G 4J1; Phone 1-800-668-1238